

Industrial Gauge Mounting Options

Mounting Options

XUC - U-Clamp



1008 - Sizes 40, 50, 63 and 100mm (Center Back)

How is it attached?	Screwed on with Set Screw
Can it be attached after?	Yes
Is it in stock?	Yes
Part Numbers	40mm 101B231-01 50mm 101B231-02 63mm 101A164-01 100mm 101A164-02

1008 - Sizes 63 and 100mm

How is it attached?	Screwed on with Set Screw
Can it be attached after?	Yes on Rear Connects and Lower Connects ordered with XLC
Is it in stock?	Yes
Part Numbers	63mm 101A164-09 100mm 101A164-10 <small>*If adapter ring is required for 100mm P/N 291A390-02</small>

Available in Lower and Back Connections



1009 - Sizes 2½" and 3½"

How is it attached?	Screwed on with Set Screw
Can it be attached after?	Yes on Rear Connects and Lower Connects ordered with XLC
Is it in stock?	Yes
Part Numbers	2½" 101A164-09* 3½" 101A164-10 <small>*Adapter ring is standard</small>

Available in Lower and Back Connections

1009 - Sizes 4½" and 6"

How is it attached?	Secure U-Clamp onto pre-welded screws which are on the back of the case
Can it be attached after?	No
Is it in stock?	NA
Part Numbers	NA

Available in Back and Lower connections

Industrial Gauge Mounting Options

Mounting Options

XFF - Front Flange



1008 - Sizes 40 and 50mm

How is it attached?	Push on from back
Can it be attached after?	Yes
Is it in stock?	Yes
Part Numbers	40mm 101B231-03 50mm 101B231-04

1008 - Size 63mm

How is it attached?	Push On In front
Can it be attached after?	Yes
Is it in stock?	Yes
Part Numbers	101A164-13
Only available in Back Connection	



1008 - Sizes 63 and 100 (Center Back) mm

How is it attached?	Push On In front
Can it be attached after?	Yes
Is it in stock?	Yes
Part Numbers	63mm 101A164-13 100mm 101A140-04

1008 - Size 100mm

How is it attached?	Screwed on back
Can it be attached after?	Yes on Rear Connects
Is it in stock?	Yes
Part Numbers	101A164-12
Only available in Back Connection	

Industrial Gauge Mounting Options

Mounting Options

XFF - Front Flange



1009 - Sizes 2½" and 3½"

How is it attached?	Screwed on back
Can it be attached after?	Yes on Rear Connects
Is it in stock?	Yes
Part Numbers	2½" 101A164-11 3½" 101A164-12

Only available in Back Connection



1009 - Sizes 4½" and 6"

How is it attached?	Pre-Welded onto Case
Can it be attached after?	No
Is it in stock?	NA
Part Numbers	NA

Only available in Back Connection



2008 - Size 63mm

How is it attached?	Pre-Welded onto Case
Can it be attached after?	Standard
Is it in stock?	NA
Part Numbers	NA

Industrial Gauge Mounting Options

Mounting Options

XFW - Back Flange



1009 - Sizes 2½" and 3½"

How is it attached?	Screwed on back
Can it be attached after?	Yes on Rear Connects and Lower Connects ordered with XLC
Is it in stock?	Yes
Part Numbers	2½" 101A164-14 3½" 101A164-15

Available in Lower and Back Connections

63mm = 2½" and 100mm = 3½" 1008 share same part numbers for XFW

XBF - Back Mounting



1009 - Sizes 4½" and 6"

How is it attached?	Screwed on with Set Screw
Can it be attached after?	NA
Is it in stock?	NA
Part Numbers	NA

Available in Back (Left); Lower (Right)

XRF - Retrofit



1008 - Sizes 63 and 100mm (Center Back)

How is it attached?	U-Clamp with Spacer
Can it be attached after?	Yes
Is it in stock?	Yes
Part Numbers	63mm 101A140-06 100mm 101A140-07